



Ensuring Each Breath:
*An Oxygen Compatible
Flowmeter for the Exploration
PLSS*

Adam Escobar

11/19/2019



Presentation Agenda



- **Portable Life Support System (PLSS) Flow Sensing History**
- **Space Lab's Innovation**
- **Phase I Results**
- **What We are Doing for Phase II**



PLSS FLOW SENSING HISTORY

Apollo PLSS

➤ **Nominal Pressure**

- 3.85 psia


Lutz, 1975

➤ **Nominal Flow Rate**

- > 5.5 acfm


➤ **Ventilation Flow Sensor**

- Provide signal to alarm module and RCU warning indicators
 - When flow drops between 4.0-5.3 acfm
- Initial approach included sensing
 - Rotational speed of fan
 - Differential pressure across fan
 - > Discontinued: due to undetectable blockage or disconnection
- Low pressure drop venturi tube downstream from the fan outlet
 - Utilized a capacitive pressure transducer
 - Initial units were sensitive to ambient temperature changes (resolved)
 - Sensitivity to condensing moisture in capacitive pressure transducer
 - Problem was 'resolved' by adding T-VAC drying requirement




Apollo PLSS Schematic

Lutz, 1975





The content of this slide is subject to the propriety statement on the title slide.




Shuttle / ISS PLSS

- **Nominal Pressure**
 - 4.3 psia
- **Adequate Flow Rate**
 - > 5.4 acfm
- **Ventilation Flow Sensor**
 - Check valve/flow sensor assembly
 - Pressure compensated
 - Bi-level readout
 - > 3.7 acfm minimum
 - < 5.4 acfm maximum

NASA EMU Data Book – Rev V., 2017




Credit: NASA, Joseph Tanner STS-115



Shuttle / ISS PLSS Schematic

NASA EMU Data Book – Rev V., 2017




The content of this slide is subject to the propriety statement on the title slide.

Exploration PLSS


- **Pressure Range**
 - 3.5 to 25 psia
- **Flow Rate Range**
 - 1 to 8 acfm
- **Two Redundant Flowmeters**
 - Differential pressure across the ventilation loop heat exchanger
 - Space Lab's innovation
- **Independent Technologies allow Increased Robustness**



Credit: NASA TV



Exploration PLSS Schematic







SPACE LAB'S INNOVATION

The Space Lab O=O Flow™

- **Low Pressure Drop**
 - < 0.04 inH₂O drop @ 4.3 psia
- **100% Oxygen Compatible**
 - Wetted Materials:
 - Inconel 625
 - Nickel 200
 - Teflon® (PTFE)
 - Viton®
- **Accurate across Multi-flow Conditions (< 1.5% Uncertainty)**
 - Laminar, Transition, Turbulent
- **Compact Formfactor**
 - 3 × 2.5 × 1.5 inch envelope
- **Use of New Flow Field Relationships**





New Differential Pressure Transducer




High Turndown: Capable of measuring DP range of 0.001 to 10 inH₂O

The content of this slide is subject to the propriety statement on the title slide.



Phase I Results

APT Differential Pressure Output vs. Flow Rate
4.3 psia



The content of this slide is subject to the propriety statement on the title slide.



WHAT WE ARE DOING FOR PHASE II

The content of this slide is subject to the propriety statement on the title slide.



Phase II Deliverables to NASA



➤ **O=O Flowmeter™ EDU**

- Engineering Demonstration Unit using commercial/industrial parts
- 4-pin Mighty Mouse connector (6-4) interface
- +5 Vdc input power (< 150 mW)
- RS-485 data interface (flow rate, pressure, temperature)

➤ **O=O Flowmeter™ Test System**

- Test system allows for immediate testing
- Can be used for debug of EDU for operation in PLSS system





**THANK YOU
TAKE A DEEP BREATH ;-)**



BACKUP SLIDES

The content of this slide is subject to the propriety statement on the title slide.



EVA from Gemini to the ISS and Beyond

Malik, 1968

Gemini Nov. 1961 – Nov. 1966

First U.S.A. EVA: Gemini IV – June 1965

Lutz, 1975

Apollo Nov. 1961 – Nov. 1966

First use of the complete EMU: Apollo 9 – March 1969

First on Lunar surface: Apollo 11 – July 1969

First two EVA periods: Apollo 12 – November 1969

First accompanied of the buddy secondary life-support system (BSLSS): Apollo 14 – Jan 1971

Commercialization

O=O Flowmeter™

EddySense™



Markets & Customers



- ❖ NASA HEOMD AES – AEMU PLSS
- ❖ STMD - Small Spacecraft Thrusters
- ❖ Producers of Commercial O₂ Delivery Systems (priority order):
 1. Commercial Space Suits
 2. Space Life Support Systems
 3. Military Breathing Equipment
 4. Satellite Propulsion Systems
 5. Commercial Harsh Environment Suits O₂
 6. Delivery Medical O₂ Therapy
 7. Industrial Process Monitoring

Value Proposition



Revenue Streams & Intellectual Property

- ❖ Years 3-5: Application specific units to beachhead customer (NASA) & markets 1-4
- ❖ 5+ Years: Sell standardized units to broader commercial markets 5-7
- ❖ 4 – 5 Patents Planned